



PARTS LIST - MODEL AG-5152



- | | |
|------------|--|
| 1. various | STENCIL PLATE (<i>Part # marked on stencil plate</i>) |
| 2. 9-1359 | FOAM GASKET |
| 3. 9-4189 | FRONT HOUSING |
| 4. 9-3215 | GRIT BAG |
| 5. 9-1060 | RIBBED GASKET (BACK) |
| 6. 9-1097 | BACKING PLATE, ALUMINUM |
| 7. 9-1415 | NOZZLE |
| 8. 9-1486 | VENTURE CHAMBER |
| 9. 9-1381 | LOCKING RINGS (2 per machine) |
| 10. 9-6009 | AIR JET |
| 11. 9-6000 | GUN FRAME ASSEMBLY (BILLET) |
| | ASSEMBLY INCLUDES: Gun Frame, Extension, Air Valve Plug, Brass Spool, Spool Spring, Trigger, Trigger Screws, Spool O-Ring, Spool Spacer, Rubber Air Valve, Air Jet, Hose Connector Fitting (see next page for assembly drawing 9-6000) |
| 12. 9-2396 | O-RING, FOR SPOOL |
| 13. 9-6001 | BRASS SPOOL |
| 14. 9-6006 | SPACER, FOR SPOOL |
| 15. 9-6007 | AIR VALVE, RUBBER |
| 16. 9-6011 | SPRING, FOR SPOOL |
| 17. 9-6003 | AIR VALVE PLUG |
| 18. 9-4510 | GRIT PICKUP PIPE |
| 19. 9-6008 | TRIGGER |
| 20. 9-6005 | TRIGGER SCREW (2 per machine) |
| 21. 9-6010 | HOSE CONNECTOR FITTING |
| 22. 9-2399 | O-RING, FOR CUP TOP |
| 23. 9-4930 | URETHANE PLUG |
| 24. 9-3600 | CUP COVER |
| 25. 9-3607 | CUP COVER GASKET |
| 26. 9-3681 | CUP COVER NUT |
| 27. 9-4300 | QUART CANISTER |
| 28. 9-2169 | CLAMP (2 per machine) |
| 29. 9-3199 | THUMB NUT, NYLON, 8-32 (8 per machine) |
| 30. 9-4999 | 8' AIR HOSE |
| 31. 9-1345 | ADJUSTING BOLTS, PIVOT POINT (2 per machine - not shown) |
| 32. 9-1348 | ADJUSTING BOLTS, PIVOT STOP (2 per machine - not shown) |

Air Jet can be removed with 3/16" Allen Key

ASSEMBLY DRAWING - 9-6000



Components shown are included when purchasing assembly 9-6000

10. 9-6009	AIR JET (NOT compatible with original 5152)
12. 9-2396	O-RING, FOR SPOOL
13. 9-6001	BRASS SPOOL
14. 9-6006	SPACER, FOR SPOOL
15. 9-6007	AIR VALVE, RUBBER
16. 9-6011	SPRING, FOR SPOOL
17. 9-6003	AIR VALVE PLUG
19. 9-6008	TRIGGER
20. 9-6005	TRIGGER SCREW (2 per machine)
21. 9-6010	HOSE CONNECTOR FITTING